EDWARD

TECHNICAL DATA





EDWARD

FITTING INSTRUCTIONS

carisa

Key	Component	Qty
A	Screw	12
B	Wall Plug	12





Assembly Instructions

Drill twelve holes on the wall and the floor.

Put the wall plug (B)into the hole.

Set the mounting brackets by centering holes on the wall and floor.

The settled brackets are fasten via twelve screws (A) on the wall.